

NOTES:

- 1. PLACE 3 TO 6 INCHES OF SAND OR GRAVEL IN BOTTOM OF EXCAVATION.
- 2. IF NECESSARY, USE CONDUIT EXTENSION AND COUPLING TO EXTEND EXISTING CONDUIT TO FINISHED GRADE.
- 3. HANDHOLE WILL BE AS PROVIDED BY THE CITY.

CITY OF ROCHESTER

FIBERGLASS HANDHOLE INSTALLATION

ISSUED 9-2-91 STD. DWG.

REVISED 4-28-06 NO. R671-5